## 3 WAY GAUGE VALVE 1/4"

## **Brass**






- •1/4" IPS
- •200 psi
- •Used to facilitate the installation of sprinkler system pressure gauges.
- •The valve provides for one inlet and two outlets.
- •Allows for replacement of the system gauge without shutting down the water supply to the sprinkler system.
- •Also allows Authorities' Having Jurisdiction to test system pressure with an additional gauge through the second outlet.

(The second outlet is normally plugged during installation with a 1/4" IPS pipe plug.)

MATERIALS			
PART	MATERIAL		
HANDLE NUT	IRON		
NAME PLATE	ALUMINUM		
HAND WHEEL	CAST IRON		
PACKING NUT	BRASS ROD		
GLAND PACKING	GRAPHITE		
STEM	BRASS ROD		
RODV	CAST BRASS		



	DIMENSIONS			
PART #	SIZE	Α	В	С
65-20-190	1/4"	2.56"	2.05"	1.65"

## Installation

Installation of the three-way valve can be accomplished with normal field installation tools. Make sure the valve is installed according to the flow indication arrow that has been cast into the valve body.

The most common installation allows for a 1/4" IPS nipple between the valve and the water supply being measured. This assures there will be adequate spacing for the sprinkler system gauge from the riser. Use either PTFE Pipe Thread Sealing Tape or a suitable pipe thread sealant such as Tuf-Glide Thread Sealant Paste with PTFE when installing the

DO NOT OVERTIGHTEN THREADS. OVERTIGHTENING MAY CAUSE VALVE FAILURE.

## **ONE YEAR WARRANTY**

This products is warranted to be free of defects in workmanship and material.

This warranty lasts one year from date purchased. Warranty coverage ends when the product becomes unusable for reasons other than defects in workmanship or material.

Failures due to misuse, abuse or normal wear and tear are not covered by this warranty. ARGCO shall not be responsible for any incidental or consequential damages.

System No.	Location	
Submitted By	Date	

Spec Section	Paragraph	
Approved	Date	

