

MAIN COMPONENTS



DESCRIPTION	ITEM #
1: PT HOUSING	3301000-HOUSING
2: PT POWER DRIVE REPAIR KIT	3301001
3: PT REAR SCREWS	3304101
4: PT REAR LOCK WASHERS	3304102
5: PT REAR CENTERING HEAD	3304103
6: PT REAR CENTERING JAWS	3304104
7: PT REAR STEP PINS	3304105
8: PT REAR CENTERING SCROLL	3304106
9: PT REAR BACK PLATE	3304107
10: PT REAR ASSEMBLY	3304108
11: PT DRIVE SHAFT	3304109
12: PT REAR BEARING	3304110
13: PT THRUST RING	3304116

DESCRIPTION	ITEM #
14: PT FRONT BEARING	3304117
15: PT JAW INSERTS	3304127
16: PT CHUCK JAWS	3304128
17: PT OCTAGONAL SNAP RING	3304131
18: PT SCREW FOR RETAINING RING	3304132
19: PT RETAINING RING	3304133
20: PT SUPPORT ARM	3304134
21: PT SUPPORT ARM REPAIR KIT	3304134KIT
22: PT SPRING RING	3304137
23: PT RING GEAR	3304140
24: PT DRIVE RING	3304141
25: PT CHUCK CAP	3304142
26: PT OUTSTANDING JAWS	3304405