




SPRINKLER HEAD GUARDS
TWO PIECE UNIVERSAL HEADGUARD



FOR PROTECTION OF SPRINKLER HEADS IN INDUSTRIAL APPLICATIONS (storage racks, low drops, etc.)



Designed to provide protection against low level impacts to the sprinkler head. Features a cage and clamping base plate. This design can provide additional protection for sprinklers that may experience greater opportunity for repeated abuse. Caution: Head guards will not protect sprinkler heads from severe abuse or impact.

Finish: Red Powder Coated

- 4530150: 1/2" IPS
- 4530157: 3/4" IPS
- 4530153: baffle plate (optional)

ARGCO's two piece universal headguards have the same design and are compatible with all sprinkler head manufacturers.

Installation requires the use of a flat head screw driver.

Place the base plate around the top thread of the sprinkler head closest to the frame.

Close the base plate around the thread. At the same time, hold the cage to the base plate until the base plate engages the cage with its four tangs.

Adjust the set screw until base plate is firmly attached to the sprinkler.

System No.		Location		Spec Section		Paragraph	
Submitted By		Date		Approved		Date	